



 Tabla de Tapas Serie 2000 y 3000 – Roscado y S.W.

Tamaño		A Roscado	B Roscado	A S.W.	B S.W. Max	C Min.	D Max.
pulg.	mm	mm	mm	mm	mm	mm	mm
1/8	3.20	16.00	19.00	17.00	15.00	10.00	10.90
1/4	6.40	19.00	25.00	22.00	15.00	10.00	14.35
3/8	9.50	22.00	25.00	25.40	15.00	10.00	17.80
1/2	12.70	29.00	32.00	31.70	17.00	10.00	21.95
3/4	19.00	35.00	37.00	38.10	20.00	13.00	27.30
1	25.40	44.40	41.00	44.40	23.00	13.00	34.05
1 1/4	31.80	57.00	44.00	57.00	23.00	13.00	42.80
1 1/2	38.00	64.00	44.00	64.00	24.00	13.00	48.90
2	51.00	76.00	48.00	76.00	29.00	16.00	61.35
2 1/2	63.50	92.00	60.00	92.00	32.00	16.00	74.20
3	76.00	108.00	65.00	108.00	35.00	16.00	90.15
4	102.00	140.00	68.00	140.00	41.00	19.00	115.80

 Tabla de Tapas Serie 6000 – Roscado y S.W.

Tamaño		A Roscado	B Roscado	A S.W.	B S.W. Max	C Min.	D Max.
pulg.	mm	mm	mm	mm	mm	mm	mm
1/8	3.20	22.00	27.00	19.00	17.00	10.00	10.90
1/4	6.40	25.00	27.00	24.00	17.00	10.00	14.35
3/8	9.50	32.00	27.00	29.00	17.00	10.00	17.80
1/2	12.70	38.10	33.00	35.00	18.00	10.00	21.95
3/4	19.00	44.40	38.00	41.20	21.00	13.00	27.30
1	25.40	57.00	43.00	50.80	24.00	13.00	34.05
1 1/4	31.80	64.00	46.00	57.00	24.00	13.00	42.80
1 1/2	38.00	76.00	48.00	67.00	26.00	13.00	48.90
2	51.00	92.00	51.00	83.00	32.00	16.00	61.35
2 1/2	63.50	108.00	64.00		35.00	16.00	74.20
3	76.00	127.00	68.00		38.00	16.00	90.15
4	102.00	159.00	75.00		48.00	19.00	115.80